## WSDOT Errata to FOP for AASHTO R 47

# Reducing Samples of Asphalt Mixtures to Testing Size

WAQTC FOP for AASHTO R 47 has been adopted by WSDOT with the following changes:

#### **Apparatus**

Include items below:

• Mechanical Splitter Type A (Quartermaster): having four equal-width chutes discharging into four appropriately sized sample receptacles. Splitter is to be equipped with a receiving hopper that will hold the sample until the release lever is activated with four sample receptacles of sufficient capacity to accommodate the reduced portion of the Asphalt Mixture sample from the mechanical splitter. Refer to AASHTO R 47, Figures 1 through 3, for configuration and required dimensions of the mechanical splitter.

## Selection of Procedure (Method)

Include items below:

- Mechanical Splitter Method
  - Type A (Quartermaster)
  - Type B (Riffle Splitter)

#### **Procedure**

Include items below:

#### Mechanical Splitter Type A (Quartermaster)

**Note:** This method is to be used for Initial Reduction of Field Sample ONLY.

- 1. Clean the splitter and apply a light coating of approved release agent to the surfaces that will contact Asphalt Mixture.
- 2. Close and secure hopper gates.
- 3. Place the four sample receptacles in the splitter so that there is no loss of material.
- 4. Remove the sample from the agency-approved container(s) and place in the mechanical splitter hopper. Avoid segregation, loss of Asphalt Mixture or the accidental addition of foreign material.
- 5. Release the handle, allowing the Asphalt Mixture to drop through the divider chutes and discharge into the four receptacles.
- 6. Any Asphalt Mixture that is retained on the surface of the splitter shall be removed and placed into the appropriate receptacle.
- 7. Close and secure the hopper gates.
- 8. Reduce the remaining Asphalt Mixture as needed by this method or a combination of the following methods as approved by the agency.

- 9. Combine the material contained in the receptacles from opposite corners and repeat the splitting process until an appropriate sample size is obtained.
- 10. Retain and properly identify the remaining unused portion of the asphalt mixture sample for further testing if required by the agency.

## **Quartering and Sectoring Methods**

**Note:** If this method is being used for Initial Reduction of Field Sample, step 3 "turning the entire sample over a minimum of 4 times" for safety reasons is not required.

#### Procedure

Include items below:

## **Sample Identification**

- 1. Each sample submitted for testing shall be accompanied by a transmittal letter completed in detail. Include the contract number, acceptance and mix design verification numbers, mix ID.
- 2. Samples shall be submitted in standard sample boxes, secured to prevent contamination and spillage.
- 3. Sample boxes shall have the following information inscribed with indelible-type marker: Contract number, acceptance and mix design verification numbers, mix ID.
- 4. The exact disposition of each quarter of the original field sample shall be determined by the agency.

**FOP AASHTO R 47 (23)** 

# REDUCING SAMPLES OF ASPHALT MIXTURES TO TESTING SIZE FOP FOR AASHTO R 47

## Scope

This procedure covers sample reduction of asphalt mixtures to testing size in accordance with AASHTO R 47-23. The reduced portion is to be representative of the original sample.

#### **Apparatus**

- Thermostatically controlled oven capable of maintaining a temperature of at least 110°C (230°F) or high enough to heat the material to a pliable condition for splitting.
- Non-contact temperature measuring device.
- Metal spatulas, trowels, metal straightedges, drywall taping knives, or a combination thereof; for removing asphalt mixture samples from the quartering device, cleaning surfaces used for splitting, etc.
- Square-tipped, flat-bottom scoop, shovel, or trowel for mixing asphalt mixture before quartering.
- Miscellaneous equipment including hot plate, non-asbestos heat-resistant gloves or mittens, pans, buckets, and cans.
- Sheeting: Non-stick heavy paper or other material as approved by the agency.
- Agency-approved release agent, free of solvent or petroleum-based material that could affect asphalt binder.
- Mechanical Splitter Type B (Riffle): having a minimum of eight equal-width chutes discharging alternately to each side with a minimum chute width of at least 50 percent larger than the largest particle size. A hopper or straight-edged pan with a width equal to or slightly smaller than the assembly of chutes in the riffle splitter to permit uniform discharge of the asphalt mixture through the chutes without segregation or loss of material. Sample receptacles of sufficient width and capacity to receive the reduced portions of asphalt mixture from the splitter without loss of material.
- Quartering Template: formed in the shape of a 90- degree cross with equal sides that exceed the diameter of the flattened cone of material sufficient to allow complete separation of the quartered sample. The height of the sides must be sufficient to extend above the thickness of the flattened cone of the sample to be quartered. Manufactured of metal that will withstand heat and use without deforming.
- Non-stick mixing surface that is hard, heat-resistant, clean, level, and large enough to permit asphalt mixture samples to be mixed without contamination or loss of material.

#### Sampling

Obtain samples according to the FOP for AASHTO R 97.

46 R47 short 23

Asphalt 14-1

**ASPHALT** 

WAQTC

FOP AASHTO R 47 (23)

#### **Sample Preparation**

The sample must be warm enough to separate. If not, warm in an oven until it is sufficiently soft to mix and separate easily. Do not exceed either the temperature or time limits specified in the test method(s) to be performed.

## **Selection of Procedure (Method)**

Refer to agency requirements when determining the appropriate method(s) of sample reduction. In general, the selection of a particular method to reduce a sample depends on the initial size of the sample vs. the size of the sample needed for the specific test to be performed. It is recommended that, for large amounts of material, the initial reduction be performed using a mechanical splitter. This decreases the time needed for reduction and minimizes temperature loss. Further reduction of the remaining asphalt mixture may be performed by a combination of the following methods, as approved by the agency.

The methods for reduction are:

- Mechanical Splitter Type B (Riffle) Method
- Quartering and Sectoring Methods
  - Quartering
  - Sectoring
- Incremental Method

#### **Procedure**

When heating of the equipment is desired, it shall be heated to a temperature not to exceed the maximum mixing temperature of the job mix formula (JMF).

# Mechanical Splitter Type B (Riffle) Method

- 1. Clean the splitter and apply a light coating of agency-approved release agent to the surfaces that will come in contact with asphalt mixture (hopper or straight-edged pan, chutes, receptacles).
- 2. Place two empty receptacles under the splitter.
- 3. Carefully empty the asphalt mixture from the agency-approved container(s) into the hopper or straight-edged pan without loss of material. Uniformly distribute from side to side of the hopper or pan.
- 4. Discharge the asphalt mixture at a uniform rate, allowing it to flow freely through the
- 5. Any asphalt mixture that is retained on the surface of the splitter shall be removed and placed into the appropriate receptacle.
- 6. Reduce the remaining asphalt mixture as needed by this method or a combination of the following methods as approved by the agency.

46 R47 short 23

Asphalt 14-2

- 7. Using one of the two receptacles containing asphalt mixture, repeat the reduction process until the asphalt mixture contained in one of the two receptacles is the appropriate size for the required test.
- 8. After each split, remember to clean the splitter hopper and chute surfaces if needed.
- 9. Retain and properly identify the remaining unused asphalt mixture sample for further testing if required by the agency.

## **Quartering and Sectoring Methods**

- 1. If needed, apply a light coating of agency-approved release agent to quartering template.
- 2. Place the sample from the agency approved container(s) into a conical pile on a hard, "non-stick," clean, level surface where there will be neither a loss of material nor the accidental addition of foreign material. The surface can be made non-stick by the application of an agency-approved release agent, or sheeting.
- 3. Mix the material thoroughly by turning the entire sample over a minimum of four times with a flat-bottom scoop; or by alternately lifting each corner of the sheeting and pulling it over the sample diagonally toward the opposite corner, causing the material to be rolled. Create a conical pile by either depositing each scoop or shovelful of the last turning on top of the preceding one or lifting both opposite corners.
- 4. Flatten the conical pile to a uniform diameter and thickness where the diameter is four to eight times the thickness. Make a visual observation to ensure that the material is homogeneous.
- 5. Divide the flattened cone into four equal quarters using the quartering template or straightedges assuring complete separation.
- 6. Reduce to appropriate sample mass by quartering or sectoring.

#### Quartering

- a. Remove diagonally opposite quarters, including all the fine material, and place in a container to be retained.
- b. Remove the quartering template, if used.
- c. Combine the remaining quarters.
- d. If further reduction is necessary, repeat Quartering Method Steps 3 through 6.
- e. Repeat until appropriate sample mass is obtained. The final sample must consist of the two remaining diagonally opposite quarters.
- f. Retain and properly identify the remaining unused portion of the asphalt mixture sample for further testing if required by the agency.

WAQTC

FOP AASHTO R 47 (23)

#### **Sectoring**

- a. Using a straightedge, obtain a sector by slicing through a quarter of the asphalt mixture from the center point to the outer edge of the quarter.
- b. Pull or drag the sector from the quarter with two straight edges or hold one edge of the straightedge in contact with quartering device.
- c. Remove an approximately equal sector from the diagonally opposite quarter and combine.
- d. If necessary, repeat until the appropriate sample mass has been obtained.
- e. Continue sectoring with the unused portion of the asphalt mixture until samples have been obtained for all required tests.
- f. Retain and properly identify the remaining unused portion of the asphalt mixture sample for further testing if required by the agency.

#### **Incremental Method**

- 1. Cover a hard, clean, level surface with sheeting. This surface shall be large enough that there will be neither a loss of material nor the accidental addition of foreign material.
- 2. Place the sample from the agency approved container(s) into a conical pile on that surface.
- 3. Mix the material thoroughly by turning the entire sample over a minimum of four times:
  - a. Use a flat-bottom scoop; or
  - b. Alternately lift each corner of the sheeting and pull it over the sample diagonally toward the opposite corner, causing the material to be rolled.
- 4. Create a conical pile by either depositing each scoop or shovelful of the last turning on top of the preceding one or lifting both opposite corners.
- 5. Grasp the sheeting and roll the conical pile into a cylinder (loaf), then flatten the top. Make a visual observation to determine that the material is homogenous.
- 6. Remove one quarter of the length of the loaf and place in a container to be saved by either:
  - a. Pull sheeting over edge of counter and drop material into container.
  - b. Use a straightedge at least as wide as the full loaf to slice off material and place into container.
- 7. Obtain an appropriate sample mass for the test to be performed; by either:
  - a. Pull sheeting over edge of counter and drop cross sections of the material into container until proper sample mass has been obtained.
  - b. Use a straightedge at least as wide as the full loaf to slice off cross sections of the material until proper sample mass has been obtained and place into container.

ASPHALT WAQTC FOP AASHTO R 47 (23)

**Note 1:** When reducing the sample to test size it is advisable to take several small increments, determining the mass each time until the proper minimum size is achieved. Unless the sample size is grossly in excess of the minimum or exceeds the maximum test size, use the sample as reduced for the test.

- 8. Repeat Step 7 until all the samples for testing have been obtained or until the final quarter of the original loaf is reached.
- 9. Retain and properly identify the remaining unused portion of the asphalt mixture sample for further testing if required by the agency.

ASPHALT

WAQTC

FOP AASHTO R 47 (23)

46\_R47\_short\_23

Asphalt 14-6

FOP AASHTO R 47 (23)

# PERFORMANCE EXAM CHECKLIST

# REDUCING SAMPLES OF ASPHALT MIXTURES TO TESTING SIZE FOP FOR AASHTO R 47

Pa	rtic	Exam I	Exam Date					
Re	Record the symbols "P" for passing or "F" for failing on each step of the checklist.							
Procedure Element			Trial 1	Trial 2				
1.		ample made soft enough to separate easily without exceeding mperature limits?						
2.		plitting apparatus and tools, if preheated, not exceeding aximum mixing temperature from the JMF?						
M	ech	anical Splitter Type B (Riffle) Method						
1.	Sı	plitter cleaned, and surfaces coated with release agent?						
2.	T	wo empty receptacles placed under splitter?						
3.		ample placed in hopper or straight edged pan without loss of aterial and uniformly distributed from side to side?						
4.		Taterial discharged across chute assembly at controlled rate all ee flow of asphalt mixture through chutes?	lowing					
5.		plitter surfaces cleaned of all retained asphalt mixture allowing the linto appropriate receptacles?	g it to					
6.	Fι	urther reduction with the riffle splitter:						
	a.	Material from one receptacle discharged across chute assemat controlled rate, allowing free flow of asphalt mixture through chutes?	bly 					
	b.	Splitting process continued until appropriate sample mass of with splitter surfaces cleaned of all retained asphalt mixture every split?						
7.		emaining unused asphalt mixture stored in suitable container, operly labeled?						

# **OVER**

21\_R47\_pr\_23

Asphalt 4-11

ASPHALT WAQTC FOP AASHTO R 47 (23)

Pr	oce	Trial 1	Trial 2	
Qι				
1.		mple placed in a conical pile on a hard, non-stick, heat-resistant litting surface such as metal or sheeting?		
2.	Sample mixed by turning the entire sample over a minimum of 4 times?			
3.	Conical pile formed and then flattened uniformly to diameter equal to about 4 to 8 times thickness?			
4.		mple divided into 4 equal quarters either with a metal quartering nplate or straightedges such as drywall taping knives?		
5.	Qι	nartering:		
	a.	Two diagonally opposite quarters removed and placed in a container to be retained?		
	b.	Two other diagonally opposite quarters combined?		
	c.	Process continued, if necessary, until appropriate sample mass has been achieved?		
6.	Sectoring:			
	a.	Using two straightedges or a quartering device and one straightedge, sector obtained from one of the quarters from the center point to the outer edge of the quarter?		
	b.	Equal sector obtained taken from the diagonally opposite quarter?		
7.	Inc	crements combined to produce appropriate sample mass?		
8.		emaining unused asphalt mixture stored in suitable container, operly labeled?		

**OVER** 

ASPHALT WAQTC

FOP AASHTO R 47 (23)

Pr	ocedure Element	Trial 1	Trial 2		
In	cremental Method				
1.	Sample placed on hard, non-stick, heat-resistant splitting surface covered with sheeting?				
2.	Sample mixed by turning the entire sample over a minimum of 4 times?				
3.	Conical pile formed?				
4.	Asphalt mixture rolled into loaf and then flattened?				
5.	The first quarter of the loaf removed by slicing off or dropping off edge of counter and set aside?				
6.	Proper sample mass sliced off or dropped off edge of counter into sample container?				
7.	Process continued until all samples are obtained or final quarter is remaining?				
8.	All remaining unused asphalt mixture stored in suitable container, properly labeled?				
Comments: First attempt: PassFail Second attempt:		Pass	_Fail		
	Examiner Signature WAQTC #:	WAQTC #:			

21\_R47\_pr\_23

Asphalt 4-13

ASPHALT

WAQTC

FOP AASHTO R 47 (23)

21\_R47\_pr\_23

Asphalt 4-14