

# Impact tables attachment, Reverification or Modification for Section 404/10 & 401

Project name: Project name

Permit number: Permit number (if known)

## Wetland impacts

Type of work <sup>1</sup>	Purpose of work <sup>2</sup>	Wetland name <sup>3</sup>	Wetland type & rating <sup>4</sup>	Duration of impact <sup>5</sup>	Area of impact (acres)	Amount of material (CY)
<i>EXAMPLE: Place fill material</i>	<i>Construction access</i>	<i>W 2.2</i>	<i>Cat II</i>	<i>Temporary</i>	<i>0.05</i>	<i>6.7</i>
<i>EXAMPLE: Excavate channel &amp; place streambed material</i>	<i>Conversion to new stream bed</i>	<i>W 2.2</i>	<i>Cat II</i>	<i>Permanent</i>	<i>Excavate: 0.01 Fill: 0.02</i>	<i>Excavate: 2 Fill: 4.5</i>

<sup>1</sup> Use the same language from the project description and drawings. Include verbs like excavate, place fill, clear and grub (mechanized), construct, and install. If two types of work are taking place in the same area, indicate in the description or area of impact column.

<sup>2</sup> Give the reason(s) why the work is being performed.

<sup>3</sup> If no official name for the wetland exists, create a unique name (such as "Wetland 1"). The name should be consistent with other project documents, such as a wetland delineation report.

<sup>4</sup> Ecology wetland category based on current Western Washington or Eastern Washington Wetland Rating System.

<sup>5</sup> Permanent, Temporary, provide the number of months of the temporary impact).

# Impact tables attachment, Reverification or Modification for Section 404/10 & 401

Project name: Project name

Permit number: Permit number (if known)

## Stream impacts

Type of work <sup>1</sup>	Purpose of work <sup>2</sup>	Waterbody name <sup>3</sup>	Impact location <sup>4</sup>	Duration of impact <sup>5</sup>	Amount of material (CY)	Area of impact (acres)	Length of impact (linear ft)
<i>EXAMPLE: Place new streambed mix</i>	<i>Line new channel</i>	<i>Water Creek</i>	<i>Channel bed</i>	<i>Permanent</i>	<i>7.4</i>	<i>0.02</i>	<i>200</i>
<i>EXAMPLE: Excavate and place fill</i>	<i>Construct wingwalls</i>	<i>Water Creek</i>	<i>In-stream</i>	<i>Permanent</i>	<i>Excavate: 2.3 Fill: 3.5</i>	<i>0.04</i>	<i>22</i>

<sup>1</sup> Use the same language from the project description and drawings. Include verbs like excavate, place fill, clear and grub (mechanized), construct, and install.

<sup>2</sup> Give the reason(s) why the work is being performed.

<sup>3</sup> If no official name for the waterbody exists, create a unique name (such as "Stream 1") The name should be consistent with other documents provided.

<sup>4</sup> Indicate whether the impact will occur in or adjacent to the waterbody. If adjacent, provide the distance between the impact and the waterbody and indicate whether the impact will occur within the 100-year flood plain.

<sup>5</sup> Permanent, Temporary, Long-Term Temporary (if long-term temp, give number of months of impact).